


Duo Merch Sled & Hybrid Merch Sled Quick Start Guide




Fold/Unfold

UNFOLD: Pull up on lower handle and lift handlebar vertical




FOLD: Pull up on lower handle and return handle flat



Lifting

1. Fully engage pallet
2. Pull handle downwards until a click is heard
3. Return handle vertical
4. Pull handle downwards until a click is heard
5. Return handle vertical



Lowering

1. Press down foot pedal
2. Pull handle downwards until a click is heard
3. Return handle vertical
4. Press down foot pedal
5. Pull handle downwards until a click is heard
6. Return handle vertical
7. Keep handle vertical while removing sled from under pallet

